

Hi-Carbon Specialty Tools

HI-CARBON SCREW, STUD & PIPE EXTRACTORS

Tyne 420

Screw & Pipe Extractors Hi-Carbon Steel - Spiral Style

Remove broken screws, bolts, threaded parts, and pipes.
Broken piece is extracted with out damage to threads.



To remove the broken threaded part:

Drill a hole in the end of the broken part (left hand spiral heavy duty drills are recommended for this drilling operation), insert extractor, then turn counterclockwise using a wrench on the exposed end of the extractor.

Part #	Screw Extractor Number EX-1	To remove Diameter of Screw 3/32 to 5/32	Diameter. of Screw Extractor Shank Point		Drill Size	No. per/pack
57100			1/8	.060	5/64	5
57110	EX-2	5/32 to 7/32	3/16	.080	7/64	5
57120	EX-3	7/32 to 9/32	1/4	1/8	5/32	5
57130	EX-4	9/32 to 3/8 and 1/8 pipe	5/16	3/16	1/4	5
57140	EX-5	3/8 to 5/8 and 1/4 pipe	7/16	1/4	17/64	5
57150	EX-6	5/8 to 7/8 and 3/8 pipe	5/8	3/8	13/32	1
57160	EX-7	7/8 to 1-1/8 and 1/2 pipe	7/8	15/32	17/32	1
57170	EX-8	1-1/8 to 1-3/8 and 3/4 pipe	11/32	3/4	13/16	1
57180	EX-9	1-3/8 up and 1" pipe	1-9/32	1	1-1/8	1
		TYPE 420 SCREW & PI	PE EXTRACT	TORS - CAF	RDED	
57107	EX-1	3/32 to 5/32"	1/8	.060	5/64	1
57117	EX-2	5/32 to 7/32"	3/16	.080	7/64	1
57127	EX-3	7/32 to 9/32	1/4	1/8	5/32	1
57137	EX-4	9/32 to 3/8 and 1/8" pipe	5/16	3/16	1/4	1
57147	EX-5	3/8 to 5/8 and 1/4" pipe	7/16	1/4	17/64	1

Type 421-AG

StudoutTM Screw, Stud and Pipe Extractors Super Premium - Square Style Forged Hi-Carbon Steel



TVDE 421 AC STUDOUT TM

 The square shape of these extractors gives the tools the ability to remove broken bolts, screws, and pipes with minimum deformation of the broken part.

• These extractors will not chew up or expand the object being removed.

SCDEW STIID & DIDE EYTDACTOD

To remove the broken threaded part: Drill a hole in the end of the broken part (left hand spiral heavy duty drills are recommended for this drilling operation), insert extractor, then turn counterclockwise using a wrench on the exposed end of the extractor.

	TIPE 421-AG STODOOT " SCREW, STOD & FIFE EXTRACTOR						
Part No. 70760	Extractor Diam Number of Sc	To remove Diameter of Screw	Ext	r. of Screw ractor k Point	Drill Size 1/8"	No. per/pack	
		3/16-9/32	3/16"	1/8"			
70770	E-2	9/32-11/32	1/4	11/64	3/16	5	
70780	E-3	11/32-1/2	5/16	7/32	1/4	5	
70800	E-4	1/2-3/4	3/8	9/32	5/16	5	
70810	E-5	5/8-7/8	7/16	21/64	3/8	5	
70820	E-6	7/8-1"	1/2	7/16	1/2	1	
70830	E-7	1"-1-1/4	5/8	1/2	9/16	1	
70860	E-8	1-1/8 - 1-1/2	3/4	9/16	5/8	1	
70870	E-9	1-1/4 - 1-3/4	7/8	5/8	11/16	1	